


9	switch cover	18	front cover ban	27	fuel tank cover			
8	inlet cover ban	17	circuit breaker	26	fuel tank cover stopper			
7	right shell	16	inlet cover	25	fuel tank rubber cover			
6	bolt 1	15	rubber feet	24	fuel tank			
5	capactor	14	Panel Parts	23	generator set			
4	capactor cover	13	inlet sponge	22	bolt 2	31	bolt 3	
3	handle cover	12	switch	21	back cover	30	spark plug cover	
2	fuel switch handle	11	inlet ban	20	bottom ban	29	left shell	
1	handle	10	AC socket	19	bolt	28	adiabatic ban	



11	Bearing	22	Cylinder	33	Seal, oil	44	Governor Ban	
10	Seal, oil	21	Cylinder Head Gasket	32	Bearing	43	Governor Shank	
9	Bolt	20	Cylinder Head	31	Carburetor Bolt	42	Bolt	
8	Governor Fork	19	Cylinder Head Cover Bolt	30	Carburetor	41	Starter Parts	
7	Governor Axes	18	Cylinder Head Nut	29	Intake Valve Bolt	40	Flywheel Nut	51
6	Left Crankcase	17	Cylinder Head Bolt	28	Intake Valve Parts	39	Flywheel	Muffler Parts
5	Stator	16	Spark Plug	27	Intake Valve Gasket	38	Bolt	Small Spring
4	Rotor	15	Cylinder Head Cover	26	Crankshaft and connecting Rod Parts	37	Ignition Winding	Governor Pull Pole
3	Rotor Bolt	14	Piston Pin	25	Piston	36	Press Line Ban	Governor Spring
2	Generator End Cover	13	Swing Block	24	Piston Ring	35	Right Crankcase	Spring
1	End Cover Bolt	12	Clip Spring	23	Cylinder Gasket	34	Crankcase Pin	Governor Bolt